



***** Not supplied with all models. If not supplied, skip step 11

1

- Step 4 **x8**
- Step 14 **x4**
- *** **x1**
- Step 11 **x4**
- x4**
- x2**

Bin & tray will vary between models

Supplied components

2

Use above template to mark holes

3

Drill marked holes

4

Attach both brackets

5

Align bottom of bracket with top of runner to measure location of mounting holes

6

Mount runner as per manufacturers instructions

7

Mount door to runners

8

Remove drawer assembly

9

Install drawer back

10

Re-install drawer assembly and adjust door

11

Attach door brackets if supplied

12

13

14

15

16